




Cold start injector





Electronic relay



Starter motor




Fuel feed pump




Fuse



Suppressor




Ignition lock




Ignition coil




Fuel pump




Control pressure regulator




Fuse box



Auxiliary air valve



Thermal time switch



Distributor