



Main wiring harness



Fuse No. 5
 Instrument cluster
 Turn signals
 Relay, CI system
 Side mirrors

- Legend:**
- A Fuse box
 - B Ignition lock
 - C Charging indicator light
 - D Starter motor
 - E Alternator
 - F Voltage regulator
 - G Connector

Ignition ON
 (engine not running)



Alternator charging

