



# Starting circuits



**Legend:**

- A Ignition lock
- B Remote starter pick-up point
- C Starter motor
- D Connector
- E Start inhibitor switch (automatic transmission)



**Starter operating**

Ignition coil voltage supplied from starter motor terminal 16