


Brake lights



Fuse No. 6

- Brake lights
- Rear interior light (265)
- Trunk light, engine compartment light

Legend:

- A Fuse box
- B Bulb failure sensor
- C Connector
- D Connector
- E Brake light switch

Brake pedal depressed

