


# Interior light - 262C




### Fuse No. 8

- Clock
- Glove box light
- Interior light
- Hazard warning flasher


### Legend:

- A Fuse box
- B Interior light, left side
- C Interior light, right side
- D Door switch, left door
- E Antenna switch
- F Door switch, right door

Switch on steering column in POS 1. Light ON.



Switch on steering column in POS 2. Light ON with any door open.



Lamp switch ON. Spotlights illuminated.

