


Air conditioning




Fuse No. 2

Heater blower
Horn

Fuse No. 4

Back-up lights
Air conditioning
Heated driver's seat
Relay, window lift

Air conditioning ON



Legend:

- A Fuse box
- B Ignition lock
- C Switch, air conditioning
- D Switch, blower
- E Solenoid valve
- F Clutch coil
- G Relay
- H Thermostat