


Cruise control

Fuse No. 2
Heater blower
Horn

Fuse No. 6
Brake lights
Rear interior light (265)
Trunk light, engine
compartment light

Centrifugal action switch,
closed at speeds in excess
of approx. 50 km/h
(35 mph)

Self-holding
relay **A**



Legend:

- A Speed control
- B Ignition lock
- C Switch, cruise control (and turn signals)
- D Fuse box
- E Fuse in wire
- F Switch, brake pedal
- G Switch, clutch pedal (man. trans.)
- H Bulb failure sensor
- J Relay