


# Cruise control

- 1 Battery
- 2 Ignition switch
- 11 Central electrical unit
- 22 Brake lights
- 29 Positive terminal strip
- 66 Brake light switch
- 85 Speedometer
- 115 Bulb failure warning sensor
- 225 Selector switch
- 226 Control unit
- 227 Vacuum pump
- 228 Switch, clutch pedal
- 229 Switch, brake pedal

- A Connector, LH A-post
- B Connector at selector switch

- Fuse No.
- 4 Brake lights
  - 12 Reversing lights



225	OFF	ON	ON Set speed	Resume
1	X	X	X	X
2		X	X	X
3			X	X
4			X	