

Anti-theft alarm

- 1 Battery
- 2 Ignition switch
- 9 Starter motor
- 11 Fusebox in central electrical unit
- 25 Roof light
- 29 Positive terminal strip
- 71 Start inhibitor switch, automatic gearboxes
- 72 Door switch, driver's door
- 73 Door switch, passenger door
- 116 Seat belt reminder, USA
- 516 Relay, anti-theft alarm
- 517 Start inhibitor relay, anti-theft alarm
- 518 Horn, anti-theft alarm
- 519 Control unit, anti-theft alarm
- 520 Switch, anti-theft alarm
- 521 Magnetic switch, anti-theft alarm

- A Connector, LH A-post
- B Connector, LH A-post

