

Power seats

- 1 Battery
- 2 Ignition switch
- 11/1-35 Fuses
- 29 Positive terminal strip
- 31 Ground terminal
- 244 Control unit
- 245 Motor, seat, forward-back
- 246 Motor, front of seat, raise-lower
- 247 Motor, rear of seat, raise-lower
- 248 Motor, backrest, forward-back
- 249 Switch, backrest
- 250 Control unit
- 261 Rheostat
- 262 Switch, backrest

- A Connector, relay board
- B Connector at seat
- C Connector under seat
- D Connector under seat
- E Connector, LH A-post
- F Connector under seat
- G Connector under seat

