

# Radio connections and power aerial

- 1 Battery
- 2 Ignition switch
- 8 8-pin socket on instrument panel
- 11/1-35 Fuses
- 29 Positive terminal strip
- 143 Loudspeaker, right front
- 144 Loudspeaker, left front
- 145 Loudspeaker, left rear
- 146 Loudspeaker, right rear
- 147 Aerial
- 148 Power aerial
- 149 Radio
- 490 Switch, power aerial
- 901 Amplifier, front
- 902 Amplifier, rear
- 903 Equaliser

- A 9-pin connector
- B Ground terminal strip, RH A-post
- C 9-pin connector
- D 9-pin connector
- E 9-pin connector
- F 9-pin connector
- G 4-pin connector
- H Connector, LH A-post
- J Connector
- K Connector

